



- 19-2. 조명사다리-좌측면 (LIGHTING LADDER-LEFT SIDE)
- 19-1. 조명사다리-우측면 (LIGHTING LADDER-RIGHT SIDE)
- 18. 영사막 (SCREEN)
- 17. 가림막 (COVER CURTAIN)
- 16. 장치봉 5 (#5 SET BATTEN)
- 15. 장치봉 4 (#4 SET BATTEN)
- 14. 하늘막상단조명 + 머리막 3 (UPPER CYC. LIGHT + #3 HOUSE BORDER)
- 13. 조명봉 3 (#3 LIGHT BATTEN)
- 12. 장치봉 3 (#3 SET BATTEN)
- 11. 끝막 2 (#2 DRAW CURTAIN)
- 10. 머리막 2 (#2 HOUSE BORDER)
- 09. 장치봉 2 (#2 SET BATTEN)
- 08. 조명봉 2 (#2 LIGHT BATTEN)
- 07. 장치봉 1 (#1 SET BATTEN)
- 06. 롤스크린 (ROLL SCREEN)
- 05-2. 다리막-좌측면 (HOUSE LEGS-LEFT SIDE)
- 05-1. 다리막-우측면 (HOUSE LEGS-RIGHT SIDE)
- 04. 머리막 1 (#1 HOUSE BORDER)
- 03. 조명봉 1 (#1 LIGHT BATTEN)
- 02. 모양막 (CONTOUR CURTAIN)
- 01. 끝막 1 (#1 DRAW CURTAIN)
- 00. 영점선 (ZERO LINE)
- 01. 앞무대조명 (APRON LIGHT)
- 02. 현수막봉 (PLACARD BATTEN)
- 03. 천장조명-좌측면 (CEILING LIGHT BATTEN-LEFT SIDE)
- 04. 천장조명-우측면 (CEILING LIGHT BATTEN-RIGHT SIDE)
- 05. 천장조명 (CEILING LIGHT BATTEN)